

Recommend

Maintenance / Service Schedule

Service Schedule	Service Job	Interval
Oil Level	Check	Weekly
First Oil Change	RA 0250 quantity use 6.5 liters per change	After the first 100 Hr.
Oil	Check oil level	Weekly
	Change	Between 500-2,000 Hr. Depending on inlet vapour
Inlet Filter Element	Check & Clean	Weekly with compressed air
	Change	Half-yearly, depending on intake vapour
Exhaust Filter	Change	Between 500-2,000 Hr. depending on inlet vapour
Oil Filter	Change	Between 500-2,000 Hr. depending on inlet vapour
Gas ballast , if equipped	Check	Weekly
Fan Cover	Check	Weekly
Electrical Connection	Check	Weekly



**Note : In case of 24 hours operation per day , it is recommended to change all consumables at every quarterly (3 Months) .We also recommend that synthetic oil be used.
Regular maintenance will ensure you save cost & long term operating life of the pump.**